

Draft Cap Assembly Instructions

1



1) Lay Draft Cap upside down on flat, protected area. Align halves end to end, and align sides.

2



2) Apply tape to the flat surface as shown.

3



3) Flip either half onto each other with the tape acting as a hinge.

4



4) Snip end of adhesive tube with scissors and apply entire contents in a zig-zag pattern on the end of the top half.

5



5) After done gluing, flip top half back over so each end is together again.

6



6) Squeeze Draft Cap together and then flip over.

7



7) Apply tape to top seam.

8



8) Place in attic over stair opening